| No | Name | No | Name |
|---|---|---|---|
| 1 | PRESS AGAIN indicator | 21 | Cup container |
| 2 | OUT OF WATER indicator | 22 | Bottom glass panel |
| 3 | REPLACE FILTER indicator | 23 | HOT ON/OFF switch |
| 4 | HOT WATER indicator | 24 | POWER ON/OFF switch |
| 5 | AMBIENT WATER indicator | 25 | Chiller unit condenser |
| 6 | COLD WATER indicator | 26 | Water heater |
| 7 | HOT WATER dispense button | 27 | Water heater control thermostat |
| 8 | AMBIENT WATER dispense button | 28 | Drain fitting |
| 9 | COLD WATER dispense button | 29 | Compressor |
| 10 | Body | 30 | Handle |
| 11 | Upper glass panel | 31 | External control panel |
| 12 | Control panel | 32 | External panel connector |
| 13 | Cup placement | 33 | External panel connecting cable |
| 14 | Tap | 34 | Water connection control thermostat |
| 15 | Drop container | 35 | Angled power cord |
| 16 | Regulation legs | 36 | Transformer |
| 17 | Movement rolls | 37 | PCB AClite-SB |
| 18 | Appliance movement support | 38 | Ozone generator |
| 19 | Drop container overfilling indicator | 39 | Filter-destructor |
| 20 | Bottle holder | | |

*Specification to Appliance Appearance*